

Warning: Trying to access array offset on value of type null in `/var/www/vhosts/amatrol.com/httpdocs/wp-content/themes/kallyas-child/dkpdf/dkpdf-index.php` on line 182

Warning: Trying to access array offset on value of type null in `/var/www/vhosts/amatrol.com/httpdocs/wp-content/themes/kallyas-child/dkpdf/dkpdf-index.php` on line 182

Warning: Trying to access array offset on value of type null in `/var/www/vhosts/amatrol.com/httpdocs/wp-content/themes/kallyas-child/dkpdf/dkpdf-index.php` on line 182

Warning: Trying to access array offset on value of type null in `/var/www/vhosts/amatrol.com/httpdocs/wp-content/themes/kallyas-child/dkpdf/dkpdf-index.php` on line 182

Warning: Trying to access array offset on value of type null in `/var/www/vhosts/amatrol.com/httpdocs/wp-content/themes/kallyas-child/dkpdf/dkpdf-index.php` on line 182

Warning: Trying to access array offset on value of type null in `/var/www/vhosts/amatrol.com/httpdocs/wp-content/themes/kallyas-child/dkpdf/dkpdf-index.php` on line 182

Warning: Trying to access array offset on value of type null in `/var/www/vhosts/amatrol.com/httpdocs/wp-content/themes/kallyas-child/dkpdf/dkpdf-index.php` on line 182

AWS Welding Symbols on Blueprints Training | eLearning Course

Welding Symbols - WXBP102-XX01XEN-E2

Objective 2: Describe the Eight Elements of a Welding Symbol

Basic Weld Symbols

Basic weld symbols indicate the type of weld to make. They are typically placed on the center of the reference line. Dimensions and finishing symbols are placed in relation to the basic weld symbol.

Basic weld symbols include:

- ✓ Groove
- ✓ Fillet
- ✓ Plug or Slot
- ✓ Spot or Projection
- ✓ Seam
- ✓ Back
- ✓ Surfacing
- ✓ Flange

Move your cursor over each weld symbol for more information.

Basic Weld Symbols							
Groove Welds							
Square	Scarf	V	Bevel	U	J	Flare-V	Flare-Bevel
Fillet	Plug or Slot	Spot or Projection	Seam	Back	Surfacing	Flange	
						Edge	Corner

This page is interactive. Click anywhere to hide the instructions.

Page 11 of 58

eLearning Course: MXBP102

Warning: foreach() argument must be of type array|object, null given in `/var/www/vhosts/amatrol.com/httpdocs/wp-content/themes/kallyas-child/dkpdf/dkpdf-index.php` on line 193

Additional Info

Requires:

- Computer (see [Computer Requirements](#))
-

Address

**Amatrol
2400 Centennial Blvd
Jeffersonville, IN 47130**

Contacts

**email: contact@amatrol.com
phone: (800) 264 8285**