

Floor-Standing Belt Conveyor Operation and Maintenance Training | eBook Curriculum



eBook: E19160

Amatrol's Floor-Standing Belt Conveyor eBook Curriculum (E19160) teaches skills related to flat belt conveyors, such as flat belt conveyor operation, adjustment, maintenance, and more. Flat belt conveyors are used in industry to transport material and packages from point-to-point at low cost. Learners study industry-relevant skills including installing, adjusting, maintaining, and inspecting flat belt conveyors.

In-Depth Curriculum

Comprehensive Floor-Standing Belt Conveyor Curriculum

Amatrol's floor-standing belt conveyor curriculum teaches key topics, including: material handling principles; types of conveyors; conveyor function and operation; conveyor safety; conveyor adjustment and installation; conveyor maintenance and inspection; and conveyor sizing. Within these topics, learners will study objectives like installing and adjusting a flat belt conveyor; calculating conveyor belt length; and calculating the linear speed of a conveyor using two methods.

Feature-Packed eBook Format Makes Learning Convenient

Amatrol's eBooks look like a real book and allow users to flip between pages with ease. Enhanced with features such as keyword searches and zoom controls that enable a user to quickly locate and view information, these eBooks are a fantastic learning tool. Amatrol's eBooks are available online and can be used by anyone with access to Amatrol's Learning Management System (LMS). Optionally, if you choose to use your own LMS, these eBooks are SCORM compatible to allow smooth integration into your current training system. Combined with our already extensive library of interactive multimedia titles, which are also SCORM compatible, users can now complete their entire course work online!

Additional Info



Requires:

- Computer (see [Computer Requirements](#))

Options:

- Floor-Standing Belt Conveyor Learning System (97-ME4D)

Address

**Amatrol
2400 Centennial Blvd
Jeffersonville, IN 47130**

Contacts

**email: contact@amatrol.com
phone: (800) 264 8285**