Warning: Undefined array key 0 in /var/www/vhosts/amatrol.com/httpdocs/wp-content/themes/kallyaschild/dkpdf/dkpdf-index.php on line 164

Warning: Trying to access array offset on value of type null in /var/www/vhosts/amatrol.com/httpdocs/wpcontent/themes/kallyas-child/dkpdf/dkpdf-index.php on line 164

Warning: Trying to access array offset on value of type null in /var/www/vhosts/amatrol.com/httpdocs/wpcontent/themes/kallyas-child/dkpdf/dkpdf-index.php on line 165

Warning: Trying to access array offset on value of type null in /var/www/vhosts/amatrol.com/httpdocs/wpcontent/themes/kallyas-child/dkpdf/dkpdf-index.php on line 167

Warning: Trying to access array offset on value of type null in /var/www/vhosts/amatrol.com/httpdocs/wpcontent/themes/kallyas-child/dkpdf/dkpdf-index.php on line 168

Warning: Trying to access array offset on value of type null in /var/www/vhosts/amatrol.com/httpdocs/wpcontent/themes/kallyas-child/dkpdf/dkpdf-index.php on line 169

Warning: Trying to access array offset on value of type null in /var/www/vhosts/amatrol.com/httpdocs/wpcontent/themes/kallyas-child/dkpdf/dkpdf-index.php on line 171

Warning: Trying to access array offset on value of type null in /var/www/vhosts/amatrol.com/httpdocs/wpcontent/themes/kallyas-child/dkpdf/dkpdf-index.php on line 171


Warning: Trying to access array offset on value of type null in /var/www/vhosts/amatrol.com/httpdocs/wpcontent/themes/kallyas-child/dkpdf/dkpdf-index.php on line 171

Warning: Trying to access array offset on value of type null in /var/www/vhosts/amatrol.com/httpdocs/wpcontent/themes/kallyas-child/dkpdf/dkpdf-index.php on line 171

Warning: Trying to access array offset on value of type null in /var/www/vhosts/amatrol.com/httpdocs/wpcontent/themes/kallyas-child/dkpdf/dkpdf-index.php on line 171

Warning: Trying to access array offset on value of type null in /var/www/vhosts/amatrol.com/httpdocs/wpcontent/themes/kallyas-child/dkpdf/dkpdf-index.php on line 171

Warning: Trying to access array offset on value of type null in /var/www/vhosts/amatrol.com/httpdocs/wpcontent/themes/kallyas-child/dkpdf/dkpdf-index.php on line 171



Amatrol's Multiple Pump Systems eBook course allows learners to study the functions and real world applications of series and parallel pumps. This course presents practical skills such as installing and operating series and parallel pumps with theoretical knowledge like measuring and graphing flow/pressure characteristics and calculating pump efficiency.

## **Multiple Pumps eBook**

## What Does a Series Pump System Do?

Series pump systems feed the output of one pump directly into the input of the next pump. This effectively raises the pressure or head of the pumped fluid. This type of system is used when one pump alone cannot create enough head to meet the requirements of the application. One application of a series pump system is to raise water in a high-rise building. The system's mulitple pumps produce the head necessary to lift the water from underground to the top floor.

## **Title Element**

Multiple Pump Systems eBook Allows Online Access to Curriculum!

Amatrol's eBooks look like a real book and allow users to flip between pages with ease. Enhanced with features such as keyword searches and zoom controls that enable a user to quickly locate and view information, these eBooks are a fantastic learning tool. Amatrol's eBooks are available online and can be used by anyone with access to Amatrol's Learning Management System (LMS). Optionally, if you choose to use your own LMS, these eBooks are SCORM compatible to allow smooth integration into your current training system. Combined with our already extensive library of interactive multimedia titles, which are also SCORM compatible, users can now complete their entire course work online!

Address

Amatrol 2400 Centennial Blvd Jeffersonville, IN 47130 <u>Contacts</u>

email: contact@amatrol.com phone: (800) 264 8285